



Parental Control • Ondemand • Pay-Per-View Purchases

ATTENTION NEW DIGITAL CUSTOMER

Your converter box is capable of receiving programming that can incur additional charges such as certain Ondemand Movies and Pay-Per-View. You have the ability to create a PIN number so only people with the PIN are able to order programs that cost additional money. It is your responsibility as the account holder to set and maintain these PIN numbers. Any purchases made are the financial responsibility of the account holder.

To set a PIN for Ondemand or Pay-Per-View authorization:

- From the remote control, press the **MENU** button twice
- Scroll to **SETUP** (using the arrow up or down button on remote)
- Press **OK**
- Scroll to **PINS SETUP**
- Press **OK**
- There will be 2 options:
 - 1) Lock **PIN** - used to block selected channels or ratings.
 - 2) Purchase **PIN** to block unauthorized purchases.
- Enter a 4 digit **PIN** number of your choice
- Press **ENTER** again to confirm
- Press **EXIT**

How to setup Parental Controls:

- From the remote control, press the **MENU** button twice
- Select **PARENTAL CONTROLS**
- Enter **PIN** (previously setup as shown above)
- Choose ratings or channels you wish to block
- Press **ENTER** again to confirm
- Press **EXIT**



After setting up the PIN, it must be entered each time a program is purchased.
Be sure to keep your PIN number private and choose one that only authorized persons know.